

BELTPACK CONFIGURATIONS

RS-501: Single-channel. Includes volume control, mic on/off button, call signal button and indicator, sidetone adjust, 4-pin headset connector, 3-pin intercom and loop-through connectors. A 4-pin headset connector accommodates dynamic microphone.

RS-502: Two-channel, dual-listen, with monaural output. Programmable switching lets user listen to both channels simultaneously, and select which channel to talk on. Includes individual volume control and mic on/off button for each channel, call signal button and indicators, sidetone adjust, 4-pin headset connector, 6-pin intercom loop-through connectors. A 4-pin headset connector accommodates dynamic microphone.

RS-502-TW: Identical to RS-502, except it has 3-pin intercom loop-through connectors. Call signaling on one channel only. Requires Model TWC-10A or TWC-104 Adapter to connect to Clear-Com 2-channel system (see "Accessories").


RS-522: Two-channel unit with binaural headset output. Allows simultaneous listening and talking in any combination on two intercom channels. Headphone output operates in a "split feed" stereo mode, feeding each channel into a separate ear of a double-muff headset, or can be combined for use with a single-muff headset. Includes individual volume control for each channel, mic on/off, call signal button and indicators, sidetone adjust, 6-pin headset connector, and 6-pin intercom connector. Headset connector accommodates dynamic microphone.

RS-522-TW: Identical to RS-522, except it has 3-pin loop-through intercom connectors. Call signaling on one channel only. Requires Model TWC-10A or TWC-104 Adapter to connect to Clear-Com 2-channel system (see "Accessories").

ACCESSORIES

RMK-1 Control Unit: Remote Mic Kill

The RMK-1 Control Unit allows microphones to be shut off from a location other than the Main Station. The mic kill can be activated by pressing a call signal button for more than five seconds or by using an external push-button. The compact device can support up to 60 Series 500 beltpacks.



RMK-1

TWC-10A Adapter: Two Channels on One 3-Pin Cable

The adapter allows the connection of Series 500-"TW" beltpacks to a 2-channel Clear-Com intercom system. The TWC-10A Adapter combines Channel A and Channel B (on two separate cables) onto a single, standard 3-pin microphone cable. The stand-alone Adapter drives up to 18 "TW" beltpacks.



TWC-10A



TWC-104

TWC-104:

Four TWC-10A Adapters in a 1 RU rack unit.

YC-36 Adapter Cable: One 6-Pin to Two 3-Pins

Plugs into the 6-pin XLR intercom connector on a RS-502 or RS-522 beltpack. The other end provides two 3-pin XLR connectors, for separate line connection to channels A and B.



YC-36

Rack-mount kits for beltpacks are available upon request. Call Clear-Com for ordering information.